DRISTUD FRU36 ROOF UNDERLAY FIRE RETARDANT, SELF-SUPPORT, SYNTHETIC ROOF UNDERLAY

DESCRIPTION DriStud FRU36 is a Fire Retardant, Self-Supporting, and Superb vapourpermeable synthetic roof underlay. It is constructed from polypropylene non-woven material, a breathable film, and another layer of polypropylene non-woven.

Once installed, this underlay serves as a secondary protective layer for roof framing, enhancing weather resistance. Additionally, it provides an air-impermeable barrier behind the roof cladding. These layers play a crucial role in the internal moisture management systems for roofs and roof cavities.

When roof underlays are in contact with roof cladding, it gets cold. Its absorbent properties effectively manage condensate. However, without passive ventilation it can lead to moisture issues including mould and mildrew growth in the roof cavity. For tray roofs, it is higly recommended the underlay is separated from the roof cladding using 10mm VB10 ventilation and drainage batten or Drainage mat to defer the dew point condenstaion from the roof cladding.

Refer to DriSpace Moisture Management Design Guide for more details.

WIND ZONES Suitable in Wind Zones up to and including "Extra High" as defined in Section: 5, NZS 3604:2011.

OVERLAPS/ SUPPORT

Printed imagery on all DriStud Roof Underlays must be facing outward with the minimum number of overlaps as possible. When overlapping is impossible with both vertical and horizontal applications; a minimum lap of 150mm os required. Upper sheets must be lapped over the lower sheets to ensure water is shed to the outer face of the underlay. DriStud FRU36 must not span more than 1.2m between adjacent supports.

DriStud FRU36 will provide temporary weather protection for up to 7 days and can be exposed to wet weather during installation. DriStud FRU36 must be supported on netting or safety mesh if used:

- On roof pitches less than 10° with vertical installation
- If the support spacing is greater than 1200mm.

www.drispace.co.nz technical@drispace.co.nz 0800 374 7883





INSTALLATION GUIDE

DRISTUD FRU36 ROOF UNDERLAY FIRE RETARDANT, SELF-SUPPORT, SYNTHETIC ROOF UNDERLAY

FIXINGS	DriStud FRU36 must be fixed at maximum 300mm centres to all framing
	members with either 6-8mm staples or 20mm long large head clouts,
	or proprietary underlay fixings. If metal roof cladding is directly fixed
	straight onto the underlay, its fixings can replace the underlay fixing
	requirements.

If installing on a roof with a pitch greater than 10° then DriStud roof **ROOF PITCHES** underlays may be installed either horizontally or vertically. >10°:

If the roof pitch is less than 10° self-support roof underlays can **ROOF PITCHES** be installed horizontally and vertically. Horizontal installation is recommended over vertical installation where possible. For vertical installation under 10° roof pitch, DriStud FRU36 must be installed over a supporting netting or equivalent system on a minimum side lap of 150mm. The netting and underlays must be installed flat and taut to ensure condensation will drain to the gutter. If any doubts, vertical laps are recommended to be sealed with 75mm wide DriStud Cool Window Flashing tape or DriStud Joining Tape to ensure it.

> As an alternative solution, DriStud FRU36 may run horizontally with the higher layers sitting on top of lower layers down to roof pitches of minimum 3° without supporting netting. The underlay must be installed flat and taut to ensure condensation will drain to the gutter. At the eaves, the roof underlay should be laid over the top of the fascia and project 20-30mm into gutter.

SAFETY

≤10°:

- The installer shall take all precautions to reduce work hazards.
- The installer of DriStud roof underlays is required to comply fully with Health and Safety in Employment Act 2002.
- Appropriate clothing, safety footwear and hand and face protection must be used in all cases.
- Safety scaffold and barriers must comply with the requirements of the Health and Safety in Employment Act 2002.

www.drispace.co.nz technical@drispace.co.nz 0800 374 7883





INSTALLATION GUIDE

DRISTUD FRU36 ROOF UNDERLAY FIRE RETARDANT, SELF-SUPPORT, SYNTHETIC ROOF UNDERLAY

LONG RUN PROFILED **METAL ROOF CLADDING**

DriStud FRU36 must be installed over the purlins by fixing to the purlins on both edges by the roof fastenings. For horizontal laying, underlay must fit tightly and be lap-taped around all penetrations to provide drainage for condensation, and be free of tears, rips, and punctures. The purlin spacing must be 150mm less than the width of the underlay. If it exceeds this spacing it must be laid vertically.

COLD ROOF DESIGN **RECOMMENDATIONS: INSTALLED UNDER** LONG RUN METAL ROOFING

- Have a minimum air gap of 25mm between the underlay and any insulation.
- Use sufficient ventilation for air flow to minimize interstitial condensation.
- Use air gap between the metal cladding and synthetic underlays where condensation risks are high.

CONDENSATION MANAGEMENT

Condensation on top can be large when air is moist and calm. Permeable underlay in contact with Permeable underlay stays a Small Space:Condensation on cladding gets cold. The resulting bit warmer, no condensation underside of cladding;often not much condensation get abosrbed by the because of small air volume.

MRM Code of Practice v24.03 - 10.11A Roof Cavity Condensation

underlay, which can be significant if the

attic air is moist.

SHED/ **INDUSTRIAL** BUILDINGS

In applications where DriStud FRU36 is used in non-residential buildings, direct and reflected UV exposure must be avoided. DriStud FRU36 will go brittle and degrade under prolonged UV exposure. UV reflection can come from surfaces such as water, white concrete, sand or pavement as well as large objects such as cars.

The suitability and compatibility of the underlay with the usage of the building must be checked prior to installation. Refer to the MRM Code of Practice for more information, or consult with industry experts or designers.

www.drispace.co.nz technical@drispace.co.nz 0800 374 7883






INSTALLATION GUIDE

DRISTUD FRU36 ROOF UNDERLAY FIRE RETARDANT, SELF-SUPPORT, SYNTHETIC ROOF UNDERLAY

CONCRETE AND METAL TILE ROOF CLADDING

DriStud FRU36 must be installed under the battens but over the rafters/ top truss chords. Anti-ponding boards should be installed at the eaves to prevent the underlay sagging with a minimum fall of 5°.

Installation Under Concrete and Metal Tile Roof



WHO CAN

Where DriStud roof underlays are used for new construction or in connection with a building consent the work should be undertaken or supervised by a Licensed Building Practitioner (LBP) where restricted building work applies. Alternatively, the installer shall have the suitable skills when installing DriStud roof underlays.

MAINTENANCE DriStud roof underlays do not require any maintenance but when exposed through removal or roof cladding, the underlays must be inspected, and any damaged areas repaired or replaced.

- **WARRANTY** TCL Hunt Ltd warrants that all DriStud roof underlays will be free from manufacturing defects. Upon receiving DriStud roof underlays, it is recommended that a visual check is made. Where defects are observed, these will be replaced at the discretion of TCL Hunt, provided they are returned to point of purchase. If installed in accordance with TCL Hunt installation requirements, TCL Hunt warrants that DriStud roof underlays will comply all relevant provisions of the NZ Building Code. DriStud FRU36 roof underlay will have a serviceability life equal to that of the roof cladding provided that:
 - The balance of the external wall is installed in accordance with the NZ Building Code, and,
 - All necessary maintenance is undertaken in respect of the external wall system.

Please refer to DriSpace website www.drispace.co.nz for more information on warranty and disclaimer.

www.drispace.co.nz technical@drispace.co.nz 0800 374 7883



